Seats, Heated Rear , (4A4),(9AK),(Q2J)


From January 2011



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.




Wiring Diagram



## Seat Heating Control Module

- J882 Seat Heating Control Module SB1 Fuse 1 (On Fuse Panel B)
- ST1 Fuse Panel 1
- SF11 Fuse 11 (On Fuse Panel F)
- T16d 16-Pin Connector
- 375 Ground Connection 10 (in Main Wiring Harness)
- 377 Ground Connection 12 (in Main Wiring Harness)
- (688) Ground Connection 2 on Center Tunnel
- (B281) Positive Connection 5 (15a) (in Main Wiring Harness)
- B317 Positive Connection 3 (30a) (in Main Wiring Harness)
- \* Refer to Applicable Wiring Diagram for Fuse Positions

## E653 Left Seat Heating Button E654 Right Seat Heating Button




(B645) Heated Seat Connection 2 (in Main Wiring Harness)

Left Seat Heating Button, Seat Heating Control Module

B731 Connection 58s (in Main Wiring Harness) 1

B732 Connection 58s (in Main Wiring Harness) 2

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



ws = white sw = black ro = red rt = red br = brown gn = green bl = blue gr = grey li = lilac vi = lilac ge = yellow or = orange rs = pink



## J882 Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not guarantee or accept any liability ( nent. Copyright by AUDI AG. T16d /9 ₽<sub>T16d</sub> T16d /16 12 11 8 0.35 0.35 1.5 0.35 0.35 1.5 sw/gn sw/ge T6t 1√4 T6u 1√3 T6u 个/1 0.5 0.5 1.5 1.5 1.5 0.5 0.5 1.5 1.5 1.5 br/bl br/ws br/bl br/ws sw/ws gn/br rt/ws sw/ws gn/br rt/ws .T2fm T2fm 1/2 T2fn = white = black = red 1.5 1.5 = red rt/ws br/ws rt/ws br/ws = brown = green bl = blue = grey G94 **Z**10 **Z**11 G95 **Z**12 **Z**13 = lilac vi = lilac = yellow 32 33 34 37 39 40 41 = orange or 4GH-1400404201 rs = pink

## Seat Heating Control Module, Left Rear Bench Seat Heating Element, Right Rear Bench Seat Heating Element

- G94 Left Rear Heated Seat Temperature Sensor
- G95 Right Rear Heated Seat Temperature Sensor
- J882 Seat Heating Control Module
- T2fm 2-Pin Connector, In the Left Rear Seat
- T2fn 2-Pin Connector, In the Right Rear Seat
- T6t 6-Pin Connector, In the Coupling Point for the Left Rear Seat
- T6u 6-Pin Connector, In the Coupling Point for the Right Rear Seat
- T16d 16-Pin Connector
- Z10 Left Rear Bench Seat Heating Element
- Z11 Left Rear Backrest Heating Element
- Z12 Right Rear Bench Seat Heating Element
- Z13 Right Rear Backrest Heating Element